

TOKUSO REBASE MR. BOND

Carefully read all information, precautions, notes before using TOKUSO REBASE MR. BOND.

■CONTENTS

MR. BOND (5.5mL).....	1
Cup	1
Brush	2

■Application

Bonding of self-curing acrylic resins with non-precious metals of metal plate dentures, etc.

■Precautions

- 1) Use MR. BOND only as directed herein. DO NOT use MR. BOND for any other application.
- 2) MR. BOND is intended for use only by licensed dental care professionals.
- 3) DO NOT use this product if the safety seals are broken or if the contents have been tampered with.
- 4) Always determine whether your patient is allergic or hypersensitive to methacrylic monomers. DO NOT use MR. BOND if a patient is allergic to or hypersensitive to these monomers. If MR. BOND causes an allergic reaction or hypersensitivity, discontinue its use immediately.
- 5) Use examination gloves (plastic, vinyl, latex) at all times while using MR. BOND to avoid the possibility of allergic reactions from methacrylic monomers. If MR. BOND comes in contact with the examination gloves, immediately dispose of the examination gloves and wash hands thoroughly with water.
- 6) AVOID CONTACT WITH EYES. In case of contact with eyes, thoroughly flush eyes with water and immediately contact a physician.
- 7) If MR. BOND comes in contact with skin, clean the skin immediately with an alcohol soaked cotton swab or gauze.
- 8) MR. BOND should not be ingested or aspirated. Ingestion or aspiration may cause serious injury.
- 9) DO NOT leave MR. BOND within the reach of patients and children.
- 10) AVOID open flames when using or disposing MR. BOND.
- 11) Close the cap immediately after each use.

■Note for Storage

- 1) Store at 0-10°C(32-50°F).
- 2) DO NOT use MR. BOND after the indicated date of expiration.

■Clinical Procedure (with a metal plate denture)

- 1) Expose the new resin surface of the denture which you intend to reline by with a carborundum-grade point, etc. Then alumina-sandblast the metal surface of the denture and wash and dry.
- 2) Apply REBASE AID uniformly to the prepared resin surface.
- 3) Apply a coat of MR. BOND uniformly to the metal plate surface you intend to reline with the attached brush.
 - ◆Apply REBASE AID first. If REBASE AID is applied after the application of MR. BOND, it may result in poor adhesion.
- 4) Reline with TOKUYAMA REBASE II (or apply other self-curing acrylic resin) using the conventional technique within 5 minutes after the application of MR. BOND.

The manufacturer is not responsible for damage or injury caused by improper use of this product. It is the personal responsibility of the user to ensure the product is suitable for an appropriate application before use.

Specifications are subjected to change without notification.

Manufacturer

Tokuyama Dental Corporation

38-9, Taitou 1-chome, Taitou-ku, Tokyo, Japan

TEL:+81-3-3835-7201

URL: <http://www.tokuyama-dental.com/>

North America

Tokuyama Dental America Inc.

Tel: (877)378 3548 (Toll-Free)